

# Installation manuel

1. Open a cut hole (dia 25mm) and 2 screw holes (screw nuts welded on the back side) on the backflash of sink. Or open 2 screw holes (insert plastic expand tubes) on the wall.



2. Connect the bottle filler with a G1/2 male inlet.





3. Screw 2 screws to fix in the position

